

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0002	MinLevel	uint8	1 to 254		1	R V	[LT]
0x0002	MinLevel	uint8	max 254		0	R V	[!LT]
0x0003	MaxLevel	uint8	MinLevel to 254		254	R V	O
0x0004	Current-Frequency	uint16	MinFrequency to MaxFrequency	P Q S		R V	FQ
0x0005	MinFrequency	uint16	all			R V	FQ
0x0006	MaxFrequency	uint16	min Min-Frequency			R V	FQ
0x0010	OnOff-TransitionTime	uint16	all		0	RW VO	O
0x0011	OnLevel	uint8	MinLevel to MaxLevel	X		RW VO	M
0x0012	OnTransitionTime	uint16	all	X	null	RW VO	O
0x0013	OffTransitionTime	uint16	all	X	null	RW VO	O
0x0014	Default-MoveRate	uint8	min 1	X	MS	RW VO	O
0x000F	Options	Options-Bitmap	desc			RW VO	M
0x4000	StartUpCurrentLevel	uint8	desc	N X		RW VM	LT

1.6.6.1. Scene Table Extensions

If the Scenes Management server cluster is implemented on the same endpoint, the following attributes SHALL be part of the ExtensionFieldSetStruct of the Scene Table. If the implicit form of the ExtensionFieldSetStruct is used, the order of the attributes in the AttributeValueList is in the given order, i.e., the attribute listed as 1 is added first:

1. CurrentLevel
2. CurrentFrequency

Attributes in the scene table that are not supported by the device (according to the FeatureMap