

- At the start of the movement/transition, or
- At the end of the movement/transition.

1.6.6.7. MinFrequency Attribute

This attribute SHALL indicate the minimum value of CurrentFrequency that is capable of being assigned. MinFrequency SHALL be less than or equal to MaxFrequency. A value of 0 indicates undefined.

1.6.6.8. MaxFrequency Attribute

This attribute SHALL indicate the maximum value of CurrentFrequency that is capable of being assigned. MaxFrequency SHALL be greater than or equal to MinFrequency. A value of 0 indicates undefined.

1.6.6.9. Options Attribute

This attribute SHALL indicate the selected options of the device.

The Options attribute is a bitmap that determines the default behavior of some cluster commands. Each command that is dependent on the Options attribute SHALL first construct a temporary Options bitmap that is in effect during the command processing. The temporary Options bitmap has the same format and meaning as the Options attribute, but includes any bits that may be overridden by command fields.

This attribute is meant to be changed only during commissioning.

Command execution SHALL NOT continue beyond the Options processing if all of these criteria are true:

- The command is one of the ‘without On/Off’ commands: Move, Move to Level, Step, or Stop.
- The On/Off cluster exists on the same endpoint as this cluster.
- The OnOff attribute of the On/Off cluster, on this endpoint, is FALSE.
- The value of the ExecuteIfOff bit is 0.

1.6.6.9.1. ExecuteIfOff Bit

If this bit is set, commands in this cluster are executed and potentially change the CurrentLevel attribute when the OnOff attribute of the On/Off cluster is FALSE.

1.6.6.9.2. CoupleColorTempToLevel Bit

If this bit is set, changes to the CurrentLevel attribute SHALL be coupled with the color temperature set in the Color Control cluster.

When not supporting the Lighting feature, this bit SHALL be zero and ignored.