

Value	Action on power up
null	Set the CurrentLevel attribute to its previous value
other values	Set the CurrentLevel attribute to this value

This behavior does not apply to reboots associated with OTA. After an OTA restart, the CurrentLevel attribute SHALL return to its value prior to the restart.

1.6.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	MoveToLevel	client ⇒ server	Y	O	M
0x01	Move	client ⇒ server	Y	O	M
0x02	Step	client ⇒ server	Y	O	M
0x03	Stop	client ⇒ server	Y	O	M
0x04	MoveToLevel- WithOnOff	client ⇒ server	Y	O	M
0x05	MoveWith- OnOff	client ⇒ server	Y	O	M
0x06	StepWith- OnOff	client ⇒ server	Y	O	M
0x07	StopWith- OnOff	client ⇒ server	Y	O	M
0x08	MoveToClos- estFrequency	client ⇒ server	Y	O	FQ

1.6.7.1. MoveToLevel Command

This command will move the device to the specified level.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Level	uint8	max 254			M
1	Transition- Time	uint16	all	X		M
2	Options- Mask	Options- Bitmap	desc			M
3	OptionsOve rride	Options- Bitmap	desc			M