

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0002	DefaultSensitivityLevel	uint8	max (SupportedSensitivityLevels - 1)	F	MS	R V	[SENSLVL]
0x0003	AlarmsActive	AlarmModeBitmap	all			R V	VIS AUD
0x0004	AlarmsSuppressed	AlarmModeBitmap	all			R V	SPRS
0x0005	AlarmsEnabled	AlarmModeBitmap	all	N	MS	R V	[VIS AUD]
0x0006	AlarmsSupported	AlarmModeBitmap	all	F		R V	VIS AUD
0x0007	SensorFault	SensorFaultBitmap	all		0	R V	O

1.8.6.1. CurrentSensitivityLevel Attribute

This attribute SHALL indicate the currently selected sensitivity level.

If a write interaction to this attribute contains an unsupported sensitivity value, a CONSTRAINT_ERROR status SHALL be returned.

1.8.6.2. SupportedSensitivityLevels Attribute

This attribute SHALL indicate the number of supported sensitivity levels by the device.

These supported sensitivity levels SHALL be ordered by sensitivity, where a value of 0 SHALL be considered the lowest sensitivity level (least sensitive) and the highest supported value SHALL be considered the highest sensitivity level.

The number of supported sensitivity levels SHOULD represent unique sensitivity levels supported by the device.

1.8.6.3. DefaultSensitivityLevel Attribute

This attribute SHALL indicate the default sensitivity level selected by the manufacturer.

1.8.6.4. AlarmsActive Attribute

This attribute SHALL indicate which specific alarm modes on the server are currently active. When