

as specified for the [AlarmsEnabled](#) attribute.

1.8.7.2.2. Effect on Receipt

If any of the requested alarm modes are not supported this command SHALL be ignored and the server SHALL return an CONSTRAINT_ERROR status code.

If all the bits are valid, the value of the [AlarmsEnabled](#) attribute SHALL be set to the value of the AlarmsToEnableDisable field.

If an alarm mode is being enabled and the trigger condition is met, the device SHALL immediately activate the alarm mode and set the associated bit in the [AlarmsActive](#) attribute.

If an alarm mode is being disabled, any alarm mode which is either in the active or suppressed state SHALL be cleared and the alarm mode SHALL be considered not active.

1.8.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	AlarmsState-Changed	INFO		V	VIS AUD
0x01	SensorFault	INFO		V	O

1.8.8.1. AlarmsStateChanged Event

This event SHALL be generated after any bits in the [AlarmsActive](#) and/or [AlarmsSuppressed](#) attributes change. This MAY occur in situations such as when internal processing by the server determines that an alarm mode becomes active or inactive, or when the [SuppressAlarm](#) or [EnableDisableAlarm](#) commands are processed in a way that some alarm modes becomes suppressed, active or inactive.

If several alarm modes change state at the same time, a single event combining multiple changes MAY be emitted instead of multiple events each representing a single change.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	AlarmsActive	Alarm-ModeBitmap	all			M
1	AlarmsSuppressed	Alarm-ModeBitmap	all			SPRS

1.8.8.1.1. AlarmsActive Field

This field SHALL indicate the state of active alarm modes, as indicated by the [AlarmsActive](#) attribute, at the time the event was generated.