

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Description	string	max 64	F	MS	R V	M
0x0001	Standard-Name-space	enum16	desc	F X	null	R V	M
0x0002	SupportedModes	list[ModeOptionStruct]	max 255	F	MS	R V	M
0x0003	Current-Mode	uint8	desc	N	MS	R V	M
0x0004	StartUp-Mode	uint8	desc	N X	MS	RW VO	O
0x0005	OnMode	uint8	desc	N X	null	RW VO	DEPONOFF

1.9.6.1. Description Attribute

This attribute describes the purpose of the server, in readable text.

For example, a coffee machine may have a Mode Select cluster for the amount of milk to add, and another Mode Select cluster for the amount of sugar to add. In this case, the first instance can have the description **Milk** and the second instance can have the description **Sugar**. This allows the user to tell the purpose of each of the instances.

1.9.6.2. StandardNamespace Attribute

This attribute, when not null, SHALL indicate a single standard namespace for any standard semantic tag value supported in this or any other cluster instance with the same value of this attribute. A null value indicates no standard namespace, and therefore, no standard semantic tags are provided in this cluster instance. Each standard namespace and corresponding values and value meanings SHALL be defined in another document.

1.9.6.3. SupportedModes Attribute

This attribute is the list of supported modes that may be selected for the CurrentMode attribute. Each item in this list represents a unique mode as indicated by the Mode field of the ModeOptionStruct. Each entry in this list SHALL have a unique value for the Mode field.

1.9.6.4. CurrentMode Attribute

This attribute represents the current mode of the server.

The value of this field must match the Mode field of one of the entries in the **SupportedModes** attribute.