

1.9.6.5. StartUpMode Attribute

The StartUpMode attribute value indicates the desired startup mode for the server when it is supplied with power.

If this attribute is not null, the CurrentMode attribute SHALL be set to the StartUpMode value, when the server is powered up, except in the case when the OnMode attribute overrides the StartUpMode attribute (see [Section 1.9.6.6.1, “OnMode with Power Up”](#)).

This behavior does not apply to reboots associated with OTA. After an OTA restart, the CurrentMode attribute SHALL return to its value prior to the restart.

The value of this field SHALL match the Mode field of one of the entries in the **SupportedModes** attribute.

If this attribute is not implemented, or is set to the null value, it SHALL have no effect.

1.9.6.6. OnMode Attribute

This attribute SHALL indicate the value of CurrentMode that depends on the state of the On/Off cluster on the same endpoint. If this attribute is not present or is set to null, it SHALL NOT have an effect, otherwise the CurrentMode attribute SHALL depend on the OnOff attribute of the On/Off cluster as described in the table below:

OnOff Change	CurrentMode Change
ON → OFF	No change
OFF → ON	Change CurrentMode to OnMode
OFF → OFF	No change
ON → ON	No change

The value of this field SHALL match the Mode field of one of the entries in the SupportedModes attribute.

1.9.6.6.1. OnMode with Power Up

If the On/Off feature is supported and the On/Off cluster attribute [StartUpOnOff](#) is present, with a value of On (turn on at power up), then the CurrentMode attribute SHALL be set to the OnMode attribute value when the server is supplied with power, except if the OnMode attribute is null.

1.9.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	ChangeTo-Mode	client ⇒ server	Y	O	M

1.9.7.1. ChangeToMode Command

On receipt of this command, if the **NewMode** field indicates a valid mode transition within the sup-