

a more specific error cannot be provided. See [Status](#) field for details.

- Provide a human readable string in the StatusText field.

If the NewMode field matches the Mode field of one entry of the SupportedModes list and the device is able to transition as requested, the server SHALL transition into the mode associated with NewMode, the ChangeToModeResponse command SHALL have the Status field set to Success, the StatusText field MAY be supplied with a human readable string or include an empty string and the CurrentMode field SHALL be set to the value of the NewMode field.

If the NewMode field is the same as the value of the CurrentMode attribute the ChangeToModeResponse command SHALL have the Status field set to Success and the StatusText field MAY be supplied with a human readable string or include an empty string.

1.10.7.2. ChangeToModeResponse Command

This command is sent by the device on receipt of the ChangeToMode command. This command SHALL have the following data fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	enum8	desc			M
1	StatusText	string	max 64			[Status == Success], M

1.10.7.2.1. Status Field

1.10.7.2.1.1. Mode Base Status Code Ranges

The following table defines the enumeration ranges for the ChangeToModeResponse command's Status field values.

Status Code Range	Range Name	Summary
0x00 to 0x3F	CommonCodes	Common standard values defined in the generic Mode Base cluster specification.
0x40 to 0x7F	DerivedClusterCodes	Derived cluster specific standard values defined in the derived Mode Base cluster specification.
0x80 to 0xBF	MfgCodes	Manufacturer specific values. For the derived Mode Base cluster instances, these are manufacturer specific under the derived cluster.

The set of Status field values defined in each of the generic or derived Mode Base cluster specifications is called StatusCode.