

Value	Name	Summary	Conformance
0x00	Stopped	The device is stopped	M
0x01	Running	The device is operating	M
0x02	Paused	The device is paused during an operation	M
0x03	Error	The device is in an error state	M

1.14.4.2. OperationalStateStruct Type

The OperationalStateStruct is used to indicate a possible state of the device.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Operational-StateID	Operational-StateEnum	all		0	M
1	OperationalState-Label	string	max 64			Operational-StateID >= 0x80 & Operational-StateID <= 0xBF

1.14.4.2.1. OperationalStateID Field

This SHALL be populated with a value from the [OperationalStateEnum](#).

1.14.4.2.2. OperationalStateLabel Field

This field is present when the OperationalStateID is from the set reserved for Manufacturer Specific States. If present, this SHALL contain a human-readable description of the operational state.

1.14.4.3. ErrorStateEnum Type

This type defines the set of known operational error values, and is derived from enum8. The following table defines the applicable ranges for values that are defined within this type. All values that are undefined SHALL be treated as reserved. As shown by the table, errors that may be specific to a certain Device Type or other modality SHALL be defined in a derived cluster of this cluster.

Value	Name	Summary
0x00 to 0x3F	GeneralErrors	Generally applicable values for error, defined herein
0x40 to 0x7F	DerivedClusterErrors	Derived Cluster defined errors
0x80 to 0xBF	ManufacturerError	Vendor specific errors