

This attribute SHALL be null if the PhaseList attribute is null or if the PhaseList attribute is an empty list.

1.14.5.3. CountdownTime Attribute

This attribute SHALL represent the estimated time left before the operation is completed, in seconds.

A value of 0 (zero) means that the operation has completed.

A value of null represents that there is no time currently defined until operation completion. This MAY happen, for example, because no operation is in progress or because the completion time is unknown.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- If it has changed due to a change in the CurrentPhase or OperationalState attributes, or
- When it changes from 0 to any other value and vice versa, or
- When it changes from null to any other value and vice versa, or
- When it increases, or
- When there is any increase or decrease in the estimated time remaining that was due to progressing insight of the server's control logic, or
- When it changes at a rate significantly different from one unit per second.

Changes to this attribute merely due to the normal passage of time with no other dynamic change of device state SHALL NOT be reported.

As this attribute is not being reported during a regular countdown, clients SHOULD NOT rely on the reporting of this attribute in order to keep track of the remaining duration.

1.14.5.4. OperationalStateList Attribute

This attribute describes the set of possible operational states that the device exposes. An operational state is a fundamental device state such as Running or Error. Details of the phase of a device when, for example, in a state of Running are provided by the CurrentPhase attribute.

All devices SHALL, at a minimum, expose the set of states matching the commands that are also supported by the cluster instance, in addition to Error. The set of possible device states are defined in the [OperationalStateEnum](#). A device type requiring implementation of this cluster SHALL define the set of states that are applicable to that specific device type.

1.14.5.5. OperationalState Attribute

This attribute specifies the current operational state of a device. This SHALL be populated with a valid OperationalStateID from the set of values in the OperationalStateList Attribute.

1.14.5.6. OperationalError Attribute

This attribute SHALL specify the details of any current error condition being experienced on the