

States are defined as Pause-compatible as follows:

- For states defined in this cluster specification, in [Table 3, “Pause Compatibility”](#).
- For states defined by derived cluster specifications, in the corresponding specifications.
- For manufacturer-specific states, by the manufacturer.

A device that is unable to honor the Pause command for whatever reason SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of CommandInvalidInState but take no further action.

Otherwise, on success:

- The OperationalState attribute SHALL be set to Paused.
- The device SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of NoError.

The following table defines the compatibility of this cluster’s states with the Pause command.

Table 3. Pause Compatibility

State Value	State Name	Pause-Compatible
0x00	Stopped	N
0x01	Running	Y
0x02	Paused	Y
0x03	Error	N

1.14.6.2. Stop Command

This command SHALL be supported if the device supports remotely stopping the operation.

On receipt of this command, the device SHALL stop its operation if it is at a position where it is safe to do so and/or permitted. Restart of the device following the receipt of the Stop command SHALL require attended operation unless remote start is allowed by the device type and any jurisdiction governing remote operation of the device.

If this command is received when already in the Stopped state the device SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of NoError but take no further action.

A device that is unable to honor the Stop command for whatever reason SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of CommandInvalidInState but take no further action.

Otherwise, on success:

- The OperationalState attribute SHALL be set to Stopped.
- The device SHALL respond with an [OperationalCommandResponse](#) command with an ErrorStateID of NoError.