

ID	Name	Direction	Response	Access	Conformance
0x00	Reset	client ⇒ server	Y	O	RESET
0x01	ModifyEnabledAlarms	client ⇒ server	Y	O	O

1.15.7.1. Reset Command

This command resets active and latched alarms (if possible). Any generated Notify event SHALL contain fields that represent the state of the server after the command has been processed.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Alarms	Alarm-Bitmap	all			M

1.15.7.1.1. Alarms Field

This field SHALL indicate a bitmap where each bit set in this field corresponds to an alarm that SHALL be reset to inactive in the State attribute unless the alarm definition requires manual intervention. If the alarms indicated are successfully reset, the response status code SHALL be SUCCESS, otherwise, the response status code SHALL be FAILURE.

1.15.7.2. ModifyEnabledAlarms Command

This command allows a client to request that an alarm be enabled or suppressed at the server.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Mask	Alarm-Bitmap	all			M

1.15.7.2.1. Mask Field

This field SHALL indicate a bitmap where each bit set in the this field corresponds to an alarm that SHOULD be enabled or suppressed. A value of 1 SHALL indicate that the alarm SHOULD be enabled while a value of 0 SHALL indicate that the alarm SHOULD be suppressed.

A server that receives this command with a Mask that includes bits that are set for unknown alarms SHALL respond with a status code of INVALID_COMMAND.

A server that receives this command with a Mask that includes bits that are set for alarms which are not supported, as indicated in the Supported attribute, SHALL respond with a status code of INVALID_COMMAND.

A server that is unable to enable a currently suppressed alarm, or is unable to suppress a currently enabled alarm SHALL respond with a status code of FAILURE; otherwise the server SHALL respond with a status code of SUCCESS.