

Value	Name	Summary	Conformance
0x02	InvalidInMode	The received request cannot be handled due to the current mode of the device.	M
0x03	InvalidSet	The set of values is invalid. For example, areas on different floors, that a robot knows it can't reach on its own.	M

1.17.5.6.2. SkipAreaStatus Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0x00	Success	Skipping the area is allowed and possible, or the device was operating at the last available area and has stopped.	M
0x01	InvalidAreaList	The SelectedAreas attribute is empty.	M
0x02	InvalidInMode	The received request cannot be handled due to the current mode of the device. For example, the CurrentArea attribute is null or the device is not operating.	M
0x03	InvalidSkippedArea	The SkippedArea field doesn't match an entry in the SupportedAreas list.	M

1.17.6. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	SupportedAreas	list[AreaStruct]	max 255		MS	R V	M