

When the device finishes operating, successfully or not, it SHALL NOT change the Progress attribute, except in the case of an unexpected end of operation as described above, or due to changes to the SupportedMaps or SupportedAreas attributes, so the clients can retrieve the progress information at that time.

NOTE

if the device implements the Operational Status cluster, or a derivation of it, in case the device fails to service any locations in the SelectedAreas list before ending the operation, it SHOULD use the Operational Status cluster to indicate that the device was unable to complete the operation (see the UnableToCompleteOperation error from that cluster specification). The clients SHOULD then read the Progress attribute, and indicate which areas have been successfully serviced (marked as completed).

1.17.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	SelectAreas	client ⇒ server	SelectAreasResponse	O	M
0x01	SelectAreas-Response	client ⇐ server	N	O	M
0x02	SkipArea	client ⇒ server	SkipAreaResponse	O	[CurrentArea Progress]
0x03	SkipAreaResponse	client ⇐ server	N	O	SkipArea

1.17.7.1. SelectAreas Command

This command is used to select a set of device areas, where the device is to operate.

On receipt of this command the device SHALL respond with a SelectAreasResponse command.

This command SHALL have the following data fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NewAreas	list[uint32]	desc			M

1.17.7.1.1. NewAreas Field

This field indicates which areas the device is to operate at.

If this field is empty, that indicates that the device is to operate without being constrained to any specific areas, and the operation will not allow skipping using the SkipArea Command, otherwise the field SHALL be a list of unique values that match the AreaID field of entries on the SupportedAreas list.