

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0009	Interconnect-COAlarm	AlarmStateEnum	all			R V	O
0x000A	Contamination-State	ContaminationStateEnum	all			R V	[SMOKE]
0x000B	Smoke-SensitivityLevel	SensitivityEnum	all			RW VM	[SMOKE]
0x000C	Expiry-Date	epoch-s	all	F		R V	O

2.11.6.1. ExpressedState Attribute

This attribute SHALL indicate the visibly- and audibly-expressed state of the alarm. When multiple alarm conditions are being reflected in the server, this attribute SHALL indicate the condition with the highest priority. Priority order of conditions is determined by the manufacturer and SHALL be supplied as a part of certification procedure. If the value of ExpressedState is not Normal, the attribute corresponding to the value SHALL NOT be Normal. For example, if the ExpressedState is set to SmokeAlarm, the value of the SmokeState will indicate the severity of the alarm (Warning or Critical). Clients SHOULD also read the other attributes to be aware of further alarm conditions beyond the one indicated in ExpressedState.

Visible expression is typically a LED light pattern. Audible expression is a horn or speaker pattern. Audible expression SHALL BE suppressed if the DeviceMuted attribute is supported and set to Muted.

2.11.6.2. SmokeState Attribute

This attribute SHALL indicate whether the device's smoke sensor is currently triggering a smoke alarm.

2.11.6.3. COState Attribute

This attribute SHALL indicate whether the device's CO sensor is currently triggering a CO alarm.

2.11.6.4. BatteryAlert Attribute

This attribute SHALL indicate whether the power resource fault detection mechanism is currently triggered at the device. If the detection mechanism is triggered, this attribute SHALL be set to Warning or Critical, otherwise it SHALL be set to Normal. The battery state SHALL also be reflected in the Power Source cluster representing the device's battery using the appropriate supported attributes and events.