

- If the MoveMode field is set to 0 (Stop), the Rate field SHALL be completely ignored.

MoveMode	Action on Receipt
Stop	If moving, stop, else ignore the command (i.e., the command is accepted but has no effect). This SHALL stop any ongoing hue and/or saturation transition.
Up	Increase the device's hue at the rate given in the Rate field. If the hue reaches the maximum allowed for the device, then wraparound and proceed from its minimum allowed value.
Down	Decrease the device's hue at the rate given in the Rate field. If the hue reaches the minimum allowed for the device, then wraparound and proceed from its maximum allowed value.

3.2.8.6. StepHue Command

This command will change the device to the requested hue value using a step and transition.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	StepMode	StepModeEnum	all			M
1	StepSize	uint8	all			M
2	Transition-Time	uint8	all			M
3	Options-Mask	Options-Bitmap	desc			M
4	OptionsOverride	Options-Bitmap	desc			M

3.2.8.6.1. StepMode Field

This field SHALL indicate the mode of the step to be performed.

3.2.8.6.2. StepSize Field

This field SHALL indicate the change to be added to (or subtracted from) the current value of the device's hue.

3.2.8.6.3. TransitionTime Field

This field SHALL indicate, in 1/10ths of a second, the time that SHALL be taken to perform the step. A step is a change in the device's hue of Step size units.