

LoopActive attribute to 1 and activate the color loop, starting from the value of the EnhancedCurrentHue attribute.

If the color loop is active, the device SHALL cycle over the complete range of values of the EnhancedCurrentHue attribute in the direction of the ColorLoopDirection attribute over the time specified in the ColorLoopTime attribute. The level of increments/decrements is application specific.

If the color loop is active (and stays active), the device SHALL immediately react on updates of the ColorLoopDirection and ColorLoopTime attributes.

3.2.8.20. StopMoveStep Command

This command is provided to allow MoveTo and Step commands to be stopped.

NOTE This automatically provides symmetry to the Level Control cluster.

NOTE The StopMoveStep command has no effect on an active color loop.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Options-Mask	Options-Bitmap	desc			M
1	OptionsOverride	Options-Bitmap	desc			M

3.2.8.20.1. OptionsMask and OptionsOverride Fields

These fields SHALL be processed according to section [Use of the OptionsMask and OptionsOverride Fields](#).

3.2.8.20.2. Effect on Receipt

Upon receipt of this command, any MoveTo, Move or Step command currently in process SHALL be terminated. The values of the CurrentHue, EnhancedCurrentHue and CurrentSaturation attributes SHALL be left at their present value upon receipt of the StopMoveStep command, and the RemainingTime attribute SHALL be set to zero.

3.2.8.21. MoveColorTemperature Command

This command allows the color temperature of the light to be moved at a specified rate.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	MoveMode	MoveModeEnum	all			M
1	Rate	uint16	all			M