

See [OperationMode Attribute](#) for a detailed description of the operation and control of the pump.

ControlMode MAY be changed at any time, even when the pump is running. The behavior of the pump at the point of changing is vendor-specific.

In the case a device does not support a specific control mode, the write interaction to this attribute with an unsupported control mode value SHALL be ignored and a response containing the status of CONSTRAINT_ERROR SHALL be returned.

4.2.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	SupplyVoltageLow	INFO		V	O
0x01	SupplyVoltageHigh	INFO		V	O
0x02	PowerMissing-Phase	INFO		V	O
0x03	SystemPressureLow	INFO		V	O
0x04	SystemPressureHigh	INFO		V	O
0x05	DryRunning	CRITICAL		V	O
0x06	MotorTemperatureHigh	INFO		V	O
0x07	PumpMotor-FatalFailure	CRITICAL		V	O
0x08	ElectronicTemperatureHigh	INFO		V	O
0x09	PumpBlocked	CRITICAL		V	O
0x0A	SensorFailure	INFO		V	O
0x0B	Electronic-NonFatalFailure	INFO		V	O
0x0C	ElectronicFatalFailure	CRITICAL		V	O
0x0D	GeneralFault	INFO		V	O
0x0E	Leakage	INFO		V	O
0x0F	AirDetection	INFO		V	O