

#### 4.3.9.13. OccupiedCoolingSetpoint Attribute

This attribute SHALL indicate the cooling mode setpoint when the room is occupied.

Refer to [Setpoint Limits](#) for constraints.

If an attempt is made to set this attribute to a value greater than [MaxCoolSetpointLimit](#) or less than [MinCoolSetpointLimit](#), a response with the status code CONSTRAINT\_ERROR SHALL be returned.

If this attribute is set to a value that is less than ([OccupiedHeatingSetpoint](#) + [MinSetpointDeadBand](#)), the value of [OccupiedHeatingSetpoint](#) SHALL be adjusted to ([OccupiedCoolingSetpoint](#) - [MinSetpointDeadBand](#)).

If the occupancy status of the room is unknown, this attribute SHALL be used as the cooling mode setpoint.

If a client changes the value of this attribute, the server supports the PRES feature, and the server either does not support the OCC feature or the Occupied bit is set on the [Occupancy](#) attribute, the value of the [ActivePresetHandle](#) attribute SHALL be set to null.

#### 4.3.9.14. OccupiedHeatingSetpoint Attribute

This attribute SHALL indicate the heating mode setpoint when the room is occupied.

Refer to [Setpoint Limits](#) for constraints.

If an attempt is made to set this attribute to a value greater than [MaxHeatSetpointLimit](#) or less than [MinHeatSetpointLimit](#), a response with the status code CONSTRAINT\_ERROR SHALL be returned.

If this attribute is set to a value that is greater than ([OccupiedCoolingSetpoint](#) - [MinSetpointDeadBand](#)), the value of [OccupiedCoolingSetpoint](#) SHALL be adjusted to ([OccupiedHeatingSetpoint](#) + [MinSetpointDeadBand](#)).

If the occupancy status of the room is unknown, this attribute SHALL be used as the heating mode setpoint.

If a client changes the value of this attribute, the server supports the PRES feature, and the server either does not support the OCC feature or the Occupied bit is set on the [Occupancy](#) attribute, the value of the [ActivePresetHandle](#) attribute SHALL be set to null.

#### 4.3.9.15. UnoccupiedCoolingSetpoint Attribute

This attribute SHALL indicate the cooling mode setpoint when the room is unoccupied.

Refer to [Setpoint Limits](#) for constraints.

If an attempt is made to set this attribute to a value greater than [MaxCoolSetpointLimit](#) or less than [MinCoolSetpointLimit](#), a response with the status code CONSTRAINT\_ERROR SHALL be returned.

If this attribute is set to a value that is less than ([UnoccupiedHeatingSetpoint](#) + [MinSetpointDeadBand](#)), the value of [UnoccupiedHeatingSetpoint](#) SHALL be adjusted to ([UnoccupiedCoolingSetpoint](#) - [MinSetpointDeadBand](#)).