

Local Temperature to float above the **UnoccupiedCoolingSetpoint** (i.e., **UnoccupiedCoolingSetpoint** + **UnoccupiedSetback**) or below the **UnoccupiedHeatingSetpoint** setpoint (i.e., **UnoccupiedHeatingSetpoint** - **UnoccupiedSetback**) before initiating a state change to bring the temperature back to the user's desired setpoint. This attribute is sometimes also referred to as the "span."

The purpose of this attribute is to allow remote configuration of the span between the desired setpoint and the measured temperature to help prevent over-cycling and reduce energy bills, though this may result in lower comfort on the part of some users.

The null value indicates the attribute is unused.

If the Thermostat client attempts to write **UnoccupiedSetback** to a value greater than **UnoccupiedSetbackMax**, the Thermostat server SHALL set its **UnoccupiedSetback** value to **UnoccupiedSetbackMax** and SHALL send a Write Attribute Response command with a Status Code field enumeration of SUCCESS response.

If the Thermostat client attempts to write **UnoccupiedSetback** to a value less than **UnoccupiedSetbackMin**, the Thermostat server SHALL set its **UnoccupiedSetback** value to **UnoccupiedSetbackMin** and SHALL send a Write Attribute Response command with a Status Code field enumeration of SUCCESS response.

4.3.9.40. UnoccupiedSetbackMin Attribute

This attribute SHALL indicate the minimum value that the Thermostat server will allow the **UnoccupiedSetback** attribute to be configured by a user.

The null value indicates the attribute is unused.

4.3.9.41. UnoccupiedSetbackMax Attribute

This attribute SHALL indicate the maximum value that the Thermostat server will allow the **UnoccupiedSetback** attribute to be configured by a user.

The null value indicates the attribute is unused.

4.3.9.42. EmergencyHeatDelta Attribute

This attribute SHALL indicate the delta between the **Calculated Local Temperature** and the **OccupiedHeatingSetpoint** or **UnoccupiedHeatingSetpoint** attributes at which the Thermostat server will operate in emergency heat mode.

If the difference between the **Calculated Local Temperature** and **OccupiedCoolingSetpoint** or **UnoccupiedCoolingSetpoint** is greater than or equal to the **EmergencyHeatDelta** and the Thermostat server's **SystemMode** attribute is in a heating-related mode, then the Thermostat server SHALL immediately switch to the **SystemMode** attribute value that provides the highest stage of heating (e.g., emergency heat) and continue operating in that running state until the **OccupiedHeatingSetpoint** value is reached. For example:

- **Calculated Local Temperature** = 10.0°C