

- [OccupiedHeatingSetpoint](#) = 16.0°C
 - [EmergencyHeatDelta](#) = 2.0°C
- ⇒ [OccupiedHeatingSetpoint](#) - [Calculated Local Temperature](#) ≥? [EmergencyHeatDelta](#)
- ⇒ 16°C - 10°C ≥? 2°C
- ⇒ TRUE >>> Thermostat server changes its SystemMode to operate in 2nd stage or emergency heat mode

The purpose of this attribute is to provide Thermostat clients the ability to configure rapid heating when a setpoint is of a specified amount greater than the measured temperature. This allows the heated space to be quickly heated to the desired level set by the user.

4.3.9.43. [ACType](#) Attribute

This attribute SHALL indicate the type of Mini Split [ACTypeEnum](#) of Mini Split AC is defined depending on how Cooling and Heating condition is achieved by Mini Split AC.

4.3.9.44. [ACCapacity](#) Attribute

This attribute SHALL indicate capacity of Mini Split AC in terms of the format defined by the [ACCapacityFormat](#) attribute

4.3.9.45. [ACRefrigerantType](#) Attribute

This attribute SHALL indicate type of refrigerant used within the Mini Split AC.

4.3.9.46. [ACCompressorType](#) Attribute

This attribute SHALL indicate the type of compressor used within the Mini Split AC.

4.3.9.47. [ACErrorCode](#) Attribute

This attribute SHALL indicate the type of errors encountered within the Mini Split AC.

4.3.9.48. [ACLouverPosition](#) Attribute

This attribute SHALL indicate the position of Louver on the AC.

4.3.9.49. [ACCoilTemperature](#) Attribute

This attribute SHALL indicate the temperature of the AC coil, as measured locally or remotely (over the network).

4.3.9.50. [ACCapacityFormat](#) Attribute

This attribute SHALL indicate the format for the [ACCapacity](#) attribute.