

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0002	PercentSetting	percent	max 100	X		RW VO	M
0x0003	PercentCurrent	percent	max 100			R V	M
0x0004	SpeedMax	uint8	1 to 100	F		R V	SPD
0x0005	SpeedSetting	uint8	max SpeedMax	X		RW VO	SPD
0x0006	SpeedCurrent	uint8	max SpeedMax	P		R V	SPD
0x0007	RockSupport	Rock-Bitmap	min 1	F		R V	RCK
0x0008	RockSetting	Rock-Bitmap	desc	P		RW VO	RCK
0x0009	WindSupport	Wind-Bitmap	min 1	F		R V	WND
0x000A	WindSetting	Wind-Bitmap	desc	P		RW VO	WND
0x000B	AirflowDirection	AirflowDirectionEnum	all	P		RW VO	DIR

4.4.6.1. FanMode Attribute

This attribute SHALL indicate the current speed mode of the fan.

This attribute SHALL be set to one of the values in [FanModeEnum](#) supported by the server as indicated in the [FanModeSequence](#) attribute. The Low value SHALL be supported if and only if the [FanModeSequence](#) attribute value is less than 4. The Medium value SHALL be supported if and only if the [FanModeSequence](#) attribute value is 0 or 2.

This attribute MAY be written by a client to request a different fan mode. The server SHALL return INVALID_IN_STATE to indicate that the fan is not in a state where this attribute can be changed to the requested value.

The server MAY have values that this attribute can never be set to or that will be ignored by the server. For example, where this cluster appears on the same or another endpoint as other clusters with a system dependency, for example the Thermostat cluster, attempting to set this attribute to Off may not be allowed by the system.

If an attempt is made to set this attribute to a value not supported by the server as indicated in the [FanModeSequence](#) attribute, the server SHALL respond with CONSTRAINT_ERROR.