

ten by a client to indicate a new airflow direction for the fan. This attribute SHALL be set to one of the values in the [AirflowDirectionEnum](#) table.

4.4.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	Step	client ⇒ server	Y	O	STEP

4.4.7.1. Step Command

This command indirectly changes the speed-oriented attributes of the fan in steps rather than using the speed-oriented attributes, [FanMode](#), [PercentSetting](#), or [SpeedSetting](#), directly. This command supports, for example, a user-operated and wall-mounted toggle switch that can be used to increase or decrease the speed of the fan by pressing the toggle switch up or down until the desired fan speed is reached. How this command is interpreted by the server and how it affects the values of the speed-oriented attributes is implementation specific.

For example, a fan supports this command, and the value of the FanModeSequence attribute is 0. The current value of the FanMode attribute is 2, or Medium. This command is received with the Direction field set to Increase. As per its specific implementation, the server reacts to the command by setting the value of the FanMode attribute to 3, or High, which in turn sets the PercentSetting and SpeedSetting (if present) attributes to appropriate values, as defined by [Section 4.4.6.3.1, “Percent Rules”](#) and [Section 4.4.6.6.1, “Speed Rules”](#) respectively.

This command supports these fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Direction	StepDirectionEnum				M
1	Wrap	bool			false	O
2	LowestOff	bool			true	O

4.4.7.1.1. Direction Field

This field SHALL indicate whether the speed-oriented attributes increase or decrease to the next step value.

4.4.7.1.2. Wrap Field

This field SHALL indicate if the speed-oriented attributes wrap between highest and lowest step value.

4.4.7.1.3. LowestOff Field

This field SHALL indicate that the fan being off (FanMode = Off, PercentSetting = 0, or SpeedSetting