

The value of this attribute SHALL only be reported in the following cases:

- When it changes from null to any other value and vice versa, or
- When it changes to 0, or
- When it increases, or
- When the closing time changes.

Meaning that clients SHOULD NOT rely on the reporting of this attribute in order to keep track of the remaining duration, due to this attribute not being reported during regular countdown.

When reading this attribute it SHALL return the remaining duration, in seconds, until the valve closes.

When the value of this attribute counts down to 0, the valve SHALL automatically transition to its closed position. The behavior of transitioning to the closed position SHALL match the behavior described in the [Close](#) command.

4.6.7.5. CurrentState Attribute

This attribute SHALL indicate the current state of the valve.

A value of null SHALL indicate that the current state is not known.

4.6.7.6. TargetState Attribute

This attribute SHALL indicate the target state, while changing the state, of the valve.

A value of null SHALL indicate that no target position is set, since the change in state is either done or failed.

4.6.7.7. CurrentLevel Attribute

This attribute SHALL indicate the current level of the valve as a percentage value, between fully closed and fully open. During a transition from one level to another level, the valve SHOULD keep this attribute updated to the best of its ability, in order to represent the actual level of the valve during the movement.

A value of 100 percent SHALL indicate the fully open position.

A value of 0 percent SHALL indicate the fully closed position.

A value of null SHALL indicate that the current state is not known.

4.6.7.8. TargetLevel Attribute

This attribute SHALL indicate the target level of the valve as a percentage value, between fully closed and fully open.

The interpretation of the percentage value is the same as for the [CurrentLevel](#) attribute.