

A value of null SHALL indicate that no target position is set, since the change of level is either done or failed.

4.6.7.9. DefaultOpenLevel Attribute

This attribute SHALL indicate the default value used for the [TargetLevel](#) attribute, when a valve transitions from the closed to the open state, caused by an [Open](#) command, if a TargetLevel field is not present in the [Open](#) command.

If the [LevelStep](#) attribute is present and the value of a write interaction to this attribute field is not 100, the value SHALL be a supported value as defined by the [LevelStep](#) attribute, such that (Value received in the write interaction) % (Value of [LevelStep](#) attribute) equals 0. If the resulting value is not 0, the requested DefaultOpenLevel value is considered an unsupported value and a CONSTRAINT_ERROR status SHALL be returned.

4.6.7.10. ValveFault Attribute

This attribute SHALL indicate any faults registered by the valve.

4.6.7.11. LevelStep Attribute

This attribute SHALL indicate the step size the valve can support.

The step size defined by this attribute is counted from 0 and the final step towards 100 MAY be different than what is defined in this attribute. For example, if the value of this attribute is 15, it results in these target values being supported; 0, 15, 30, 45, 60, 75, 90 and 100.

The values of 0 and 100 SHALL always be supported, regardless of the value of this attribute.

4.6.8. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	Open	client ⇒ server	Y	O	M
0x01	Close	client ⇒ server	Y	O	M

4.6.8.1. Open Command

This command is used to set the valve to its open position.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	OpenDuration	elapsed-s	min 1	X		O
1	TargetLevel	percent	min 1			[LVL]

4.6.8.1.1. OpenDuration Field

This field SHALL indicate the duration that the valve will remain open for this specific Open com-