

4.6.8.2. Close Command

This command is used to set the valve to its closed position.

4.6.8.2.1. Effect on Receipt

If the device has registered a fault that causes it to prevent the valve to perform the requested action, the command SHALL be ignored and a `FailureDueToFault` status SHALL be returned.

The `OpenDuration` and `RemainingDuration` attribute SHALL be set to null.

If the device supports the TimeSync feature, the `AutoCloseTime` attribute SHALL be set to null.

The device SHALL set the `TargetState` attribute to the Closed value and set the `CurrentState` attribute to the Transitioning value.

If the device supports the Level feature, it SHALL set the `TargetLevel` attribute to 0.

When the relevant target attributes have been set, the device SHALL start the movement towards the target value. If the device supports the Level feature, the device SHALL update the `CurrentLevel` attribute, accordingly during the movement. When the movement is complete, the device SHALL set the `CurrentState` attribute to the Closed value.

4.6.9. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	ValveState-Changed	INFO		V	O
0x01	ValveFault	INFO		V	O

4.6.9.1. ValveStateChanged Event

This event SHALL be generated when the valve state changed. For level changes, after the end of movement, for state changes when the new state has been reached.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ValveState	<code>ValveStateEnum</code>	all			M
1	ValveLevel	percent	all			LVL

4.6.9.1.1. ValveState Field

This field SHALL indicate the new state of the valve.

4.6.9.1.2. ValveLevel Field

This field SHALL indicate the new level of the valve.