

it would follow for the ClearCredential command before adding the new credential.

If there are no available credential slots to add a new AliroEvictableEndpointKey credential (i.e. either the NumberOfCredentialsSupportedPerUser or the NumberOfAliroEndpointKeysSupported limit has been reached) and there do not exist credentials of type AliroEvictableEndpointKey associated with the user record, a new AliroEvictableEndpointKey credential SHALL NOT be created.

If the step-up process results in addition of new credentials, the corresponding LockUserChange event SHALL have OperationSource set to [Aliro](#).

If the step-up process results in the lock state changing (e.g. locking or unlocking), the credential associated with those changes in the LockOperation events SHALL be the newly provisioned AliroEvictableEndpointKey credential if one was created. If no new AliroEvictableEndpointKey credential was created, the credential associated with the changes in the LockOperation events SHALL be the AliroCredentialIssuerKey credential used for the step-up.

5.2.6.9.2. AliroEvictableEndpointKey Value

Credentials of this type SHALL be 65-byte uncompressed elliptic curve public keys as defined in section 2.3.3 of [SEC 1](#).

5.2.6.9.3. AliroNonEvictableEndpointKey Value

Credentials of this type SHALL be 65-byte uncompressed elliptic curve public keys as defined in section 2.3.3 of [SEC 1](#).

5.2.6.10. DataOperationTypeEnum Type

This data type is derived from enum8.

This enumeration SHALL indicate the data operation performed.

Value	Name	Summary	Conformance
0	Add	Data is being added or was added	M
1	Clear	Data is being cleared or was cleared	M
2	Modify	Data is being modified or was modified	M

5.2.6.11. DoorStateEnum Type

This data type is derived from enum8.

This enumeration SHALL indicate the current door state.

Value	Name	Summary	Conformance
0	DoorOpen	Door state is open	DPS