

ID	Name	Direction	Response	Access	Conformance
0x16	SetRFIDCode	client ⇒ server	Y	A T	!USR & RID
0x17	GetRFIDCode	client ⇒ server	GetRFID-CodeResponse	A	!USR & RID
0x17	GetRFID-CodeResponse	client ⇐ server	N		!USR & RID
0x18	ClearRFID-Code	client ⇒ server	Y	A T	!USR & RID
0x19	ClearAllRFID-Codes	client ⇒ server	Y	A T	!USR & RID
0x1A	SetUser	client ⇒ server	Y	A T	USR
0x1B	GetUser	client ⇒ server	GetUserResponse	A	USR
0x1C	GetUserResponse	client ⇐ server	N		USR
0x1D	ClearUser	client ⇒ server	Y	A T	USR
0x22	SetCredential	client ⇒ server	SetCredential-Response	A T	USR
0x23	SetCredential-Response	client ⇐ server	N		USR
0x24	GetCredential-Status	client ⇒ server	GetCredential-StatusResponse	A	USR
0x25	GetCredential-StatusResponse	client ⇐ server	N		USR
0x26	ClearCredential	client ⇒ server	Y	A T	USR
0x27	UnboltDoor	client ⇒ server	Y	O T	UBOLT
0x28	SetAliroReaderConfig	client ⇒ server	Y	A T	ALIRO
0x29	ClearAliroReaderConfig	client ⇒ server	Y	A T	ALIRO

5.2.10.1. LockDoor Command

This command causes the lock device to lock the door. This command includes an optional code for the lock. The door lock MAY require a PIN depending on the value of the [RequirePINForRemoteOperation](#) attribute.