

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M
1	UserStatus	UserStatusEnum	desc	X		M
2	UserType	UserTypeEnum	desc	X		M
3	RFIDCode	octstr		X		M

If the requested User ID is valid and the Code doesn't exist, Get RFID Code Response SHALL have the following format:

User ID = requested User ID

UserStatus = 0 (available)

UserType = 0xFF (not supported)

RFID Code = 0 (zero length)

If requested User ID is invalid, send Default Response with an error status. The error status SHALL be equal to CONSTRAINT_ERROR when User_ID is less than the max number of users supported, and NOT_FOUND if greater than or equal to the max number of users supported.

5.2.10.30. ClearRFIDCode Command

Clear an RFID code or all RFID codes.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	RFIDSlotIndex	uint16	1 to NumberOfRFIDUsersSupported, 0xFFFFE			M

For each RFID Code cleared whose user doesn't have a PIN Code or other credential type, then the corresponding user record's UserStatus value SHALL be set to Available, and UserType value SHALL be set to UnrestrictedUser and all schedules SHALL be cleared.

5.2.10.30.1. RFIDSlotIndex Field

This field SHALL indicate a valid RFID code slot index or 0xFFFFE to indicate all RFID code slots SHALL be cleared.

5.2.10.31. ClearAllRFIDCodes Command

Clear out all RFIDs on the lock. If you clear all RFID codes and this user didn't have a PIN code, the