

ID	Name	Direction	Response	Access	Conformance
0x02	StopMotion	client ⇒ server	Y	O	M
0x05	GoToLiftPer- centage	client ⇒ server	Y	O	(LF & PA_LF), [LF]
0x08	GoToTiltPer- centage	client ⇒ server	Y	O	(TL & PA_TL), [TL]

5.3.7.1. UpOrOpen Command

Upon receipt of this command, the window covering will adjust its position so the physical lift/slide and tilt is at the maximum open/up position. This will happen as fast as possible. The server attributes SHALL be updated as follows:

if the PositionAware feature is supported:

- TargetPositionLiftPercent100ths attribute SHALL be set to 0.00%.
- TargetPositionTiltPercent100ths attribute SHALL be set to 0.00%.

The server positioning attributes will follow the movements, once the movement has successfully finished, the server attributes SHALL be updated as follows:

if the PositionAware feature is supported:

- CurrentPositionLiftPercent100ths attribute SHALL be 0.00%.
- CurrentPositionLiftPercentage attribute SHALL be 0%.
- CurrentPositionTiltPercent100ths attribute SHALL be 0.00%.
- CurrentPositionTiltPercentage attribute SHALL be 0%.

if the AbsolutePosition feature is supported:

- CurrentPositionLift attribute SHALL be equal to the InstalledOpenLimitLift attribute.
- CurrentPositionTilt attribute SHALL be equal to the InstalledOpenLimitTilt attribute.

5.3.7.2. DownOrClose Command

Upon receipt of this command, the window covering will adjust its position so the physical lift/slide and tilt is at the maximum closed/down position. This will happen as fast as possible. The server attributes supported SHALL be updated as follows:

if the PositionAware feature is supported:

- TargetPositionLiftPercent100ths attribute SHALL be set to 100.00%.
- TargetPositionTiltPercent100ths attribute SHALL be set to 100.00%.

The server positioning attributes will follow the movements, once the movement has successfully finished, the server attributes SHALL be updated as follows: