

A properly configured closure dimension SHOULD reflect as best as possible the rotation axis as perceived by the user. This attribute is not supposed to change once the installation is finalized.

5.5.7.10. Overflow Attribute

This attribute SHALL indicate the overflow related to Rotation(RO).

A closure that rotates following an axis (with Rotation(RO) feature declared in FeatureMap), could overflow Inside and/or Outside. If the axis is centered, one part goes Outside and the other part goes Inside. In this case, this attribute SHALL use Top/Bottom/Left/Right Inside or Top/Bottom/Left/Right Outside enumerated value.

5.5.7.11. ModulationType Attribute

This attribute SHALL indicate the modulation type related to Modulation(MD).

The server SHOULD reflect, as best as possible, the modulation type as perceived by the user. This attribute is not supposed to change once the installation is finalized.

5.5.7.12. LatchControlModes Attribute

This attribute SHALL specify whether the latch mechanism can be latched or unlatched remotely.

5.5.8. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	SetTarget	client ⇒ server	Y	O T	M
0x01	Step	client ⇒ server	Y	O T	PS

5.5.8.1. SetTarget Command

This command is used to move a dimension of the closure to a target position.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Position	percent100ths			desc	O.a+
1	Latch	bool			desc	O.a+
2	Speed	ThreeLevelAutoEnum			Auto	O.a+

The rationale behind defining the conformance as being purely optional in the table above is to ensure that commands containing one or more fields related to unsupported features are still accepted, rather than being rejected outright. For example, if a simple client, which is not able to determine the capabilities of the server, invokes a command that includes both position and speed, a server that does not support the speed feature would simply ignore the speed field while still adjusting its position as requested.