

6.6.7.2. ChangeChannelResponse Command

This command SHALL be generated in response to a ChangeChannel command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	StatusEnum	desc			M
1	Data	string	any			O

6.6.7.2.1. Status Field

This field SHALL indicate the status of the command which resulted in this response.

6.6.7.2.2. Data Field

This field SHALL indicate Optional app-specific data.

6.6.7.3. ChangeChannelByNumber Command

Change the channel to the channel with the given Number in the *ChannelList* attribute.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	MajorNumber	uint16	all			M
1	MinorNumber	uint16	all			M

6.6.7.3.1. MajorNumber Field

This field SHALL indicate the channel major number value (ATSC format) to which the channel should change.

6.6.7.3.2. MinorNumber Field

This field SHALL indicate the channel minor number value (ATSC format) to which the channel should change.

6.6.7.4. SkipChannel Command

This command provides channel up and channel down functionality, but allows channel index jumps of size *Count*.

Jumps are relative to the available list of channels. For example, when the current channel is 100.0 and the list of available channels is [100.0, 200.0, 201.0, 305.1], a SkipChannel command with jump value of 2 SHALL change the channel to 201.0.

When the value of the increase or decrease is larger than the number of channels remaining in the given direction, then the behavior SHALL be to return to the beginning (or end) of the channel list