

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	DeltaPositionMilliseconds	uint64	all			M

6.10.7.9.1. DeltaPositionMilliseconds Field

This field SHALL indicate the duration of the time span to skip forward in the media, in milliseconds. In case the resulting position falls in the middle of a frame, the server SHALL set the position to the beginning of that frame and set the SampledPosition attribute on the cluster accordingly. If the resultant position falls beyond the furthest valid position in the media the client MAY seek forward to, the position should be set to that furthest valid position. If the SampledPosition attribute is supported it SHALL be updated on the cluster accordingly.

6.10.7.10. SkipBackward Command

This command is used to skip backward in the media.

Upon receipt, this SHALL Skip backward in the media by the given number of milliseconds, using the data as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	DeltaPositionMilliseconds	uint64	all			M

6.10.7.10.1. DeltaPositionMilliseconds Field

This field SHALL indicate the duration of the time span to skip backward in the media, in milliseconds. In case the resulting position falls in the middle of a frame, the server SHALL set the position to the beginning of that frame and set the SampledPosition attribute on the cluster accordingly. If the resultant position falls before the earliest valid position to which a client MAY seek back to, the position should be set to that earliest valid position. If the SampledPosition attribute is supported it SHALL be updated on the cluster accordingly.

6.10.7.11. Seek Command

This command is used to seek to a specific position in the media.

Upon receipt, this SHALL change the playback position in the media to the given position using data as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Position	uint64	all			M