

tinue to clean.

#### 7.2.7.2.3. Mapping Tag

The device was asked to create a map of the space it is located in, so it may be actively running, or paused due to an error, due to a pause command, or for recharging etc. If currently paused and the device can resume, it will continue to map.

#### NOTE

this mode is intended to be used so the current space can be mapped by the device if the robot has not previously done that, or if the layout has substantially changed, for an optimal subsequent cleaning experience.

### 7.2.8. Mode Use

If the DirectModeChange feature is not present:

- Clients SHALL start a cleaning cycle by switching from a mode with the Idle mode tag to a mode with the Cleaning mode tag.
- Clients SHALL stop a cleaning cycle by switching from a mode with the Cleaning mode tag to a mode with the Idle mode tag.
- Clients SHALL start a mapping cycle by switching from a mode with the Idle mode tag to a mode with the Mapping mode tag.
- Clients SHALL stop a mapping cycle by switching from a mode with the Mapping mode tag to a mode with the Idle mode tag.

If the DirectModeChange feature is present, clients MAY change between run modes without needing to set an Idle mode first.

The RVC Run Mode cluster's SupportedModes attribute MAY include multiple modes with the Cleaning mode tag, and/or modes with the Mapping mode tag.

### 7.2.9. Mode Change Restrictions

The server MAY refuse attempts to switch the RVC Run Mode from a mode without the Idle mode tag to another non-Idle mode, as indicated by the DirectModeChange feature.

## 7.3. RVC Clean Mode Cluster

This cluster is derived from the Mode Base cluster and defines additional mode tags and namespace enumerated values for the cleaning type of robotic vacuum cleaner devices.

### 7.3.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.