

Mode Tag Value	Name
0x0005	Vacation
0x0006	Min
0x0007	Max
0x0008	Night
0x0009	Day
0x4000	Bake
0x4001	Convection
0x4002	Grill
0x4003	Roast
0x4004	Clean
0x4005	Convection Bake
0x4006	Convection Roast
0x4007	Warming
0x4008	Proofing
0x4009	Steam

8.11.7.1.1. Bake Tag

This mode sets the device into baking mode for baking food items.

8.11.7.1.2. Convection Tag

This mode sets the device into convection mode which creates an airflow within the device during the cooking duration.

8.11.7.1.3. Grill Tag

This mode sets the device into grill mode for grilling food items. This is the same as Broil for many regions.

8.11.7.1.4. Roast Tag

This mode sets the device into roast mode for roasting food items.

8.11.7.1.5. Clean Tag

This mode sets the device into cleaning mode to clean the internal components of the appliance.

8.11.7.1.6. Convection Bake Tag

This mode sets the device into convection bake mode which creates an airflow within the device during the baking duration.