

9.1.6.1. PowerThreshold Field

This field SHALL indicate the instantaneous power demand that can be distributed to the customer without any risk of overload. The value is in mW and could be provided by the contract or Distribution Network Operator (DNO).

9.1.6.2. ApparentPowerThreshold Field

This field SHALL indicate the instantaneous apparent power demand that can be distributed to the customer without any risk of overload. The value is in mVA and could be provided by the contract or Distribution Network Operator (DNO).

9.1.6.3. PowerThresholdSource Field

This field SHALL indicate the reason why the [PowerThreshold](#) field was set. If the reason is unavailable, this field SHALL be null.

9.1.7. Cluster List

This section lists the Energy Management specific clusters as specified in this chapter.

Table 16. Overview of the Energy Management Clusters

Cluster ID	Cluster Name	Description
0x0098	Device Energy Management	Generic cluster for enabling power adjustment, sharing power forecasts and modifying power forecasts for devices
0x0099	Energy EVSE	Commands and attributes for controlling an EVSE
0x009D	Energy EVSE Mode	Commands and attributes for setting the mode of an EVSE
0x0094	Water Heater Management	Commands and attributes for controlling a Water Heater
0x009E	Water Heater Mode	Commands and attributes for setting the mode of a Water Heater
0x009B	Energy Preference	Attributes and commands for expressing user preferences around energy consumption
0x009F	Device Energy Management Mode	Commands and attributes for setting the mode of devices with energy management capability
0x0095	Commodity Price	Commands and attributes for reporting price