

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
1	ActiveSlot-Number	uint16	all	X			M
2	StartTime	epoch-s	all				M
3	EndTime	epoch-s	all				M
4	Earliest-StartTime	epoch-s	all	X			STA
5	LatestEnd-Time	epoch-s	all				STA
6	IsPausable	bool	all				M
7	Slots	list[Slot-Struct]	max 10				M
8	ForecastUp-dateReason	ForecastUp-dateReasonEnum	all				M

9.2.7.13.1. ForecastID Field

This field SHALL indicate the sequence number for the current forecast. If the ESA updates a forecast, it shall monotonically increase this value.

The ESA does not need to persist this value across reboots, since the EMS SHOULD be able to detect that any previous subscriptions are lost if a device reboots. The loss of a subscription and subsequent re-subscription allows the EMS to learn about any new forecasts.

The value of ForecastID is allowed to wrap.

9.2.7.13.2. ActiveSlotNumber Field

This field SHALL indicate which element of the Slots list is currently active in the Forecast sequence. A null value indicates that the sequence has not yet started.

9.2.7.13.3. StartTime Field

This field SHALL indicate the planned start time, in UTC, for the entire Forecast.

9.2.7.13.4. EndTime Field

This field SHALL indicate the planned end time, in UTC, for the entire Forecast.

9.2.7.13.5. EarliestStartTime Field

This field SHALL indicate the earliest start time, in UTC, that the entire Forecast can be shifted to.

A null value indicates that it can be started immediately.