

9.2.7.13.6. LatestEndTime Field

This field SHALL indicate the latest end time, in UTC, for the entire Forecast.

e.g. for an EVSE charging session, this may indicate the departure time for the vehicle, by which time the charging session must end.

9.2.7.13.7. IsPausable Field

This field SHALL indicate that some part of the Forecast can be paused. It aims to allow a client to read this flag and if it is false, then none of the slots contain SlotIsPausable set to true. This can save a client from having to check each slot in the list.

9.2.7.13.8. Slots Field

This field SHALL contain a list of SlotStructs.

It SHALL contain at least 1 entry, and a maximum of 10.

9.2.7.13.9. ForecastUpdateReason Field

This field SHALL contain the reason the current Forecast was generated.

9.2.7.14. SlotStruct Type

This indicates a specific stage of an ESA's operation.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	MinDuration	elapsed-s	all				M
1	MaxDuration	elapsed-s	all				M
2	DefaultDuration	elapsed-s	all				M
3	ElapsedSlotTime	elapsed-s	all				M
4	RemainingSlotTime	elapsed-s	all				M
5	SlotIsPausable	bool	all				PAU
6	MinPauseDuration	elapsed-s	all				PAU