

9.2.7.16.1. StartTime Field

This field SHALL indicate the start time of the constraint period that the client wishes the ESA to compute a new Forecast.

This value is in UTC and SHALL be in the future.

9.2.7.16.2. Duration Field

This field SHALL indicate the duration of the constraint in seconds.

9.2.7.16.3. NominalPower Field

This field SHALL indicate the nominal power that client wishes the ESA to operate at during the constrained period. It SHALL be between the [AbsMinPower](#) and [AbsMaxPower](#) attributes as advertised by the ESA if it supports **PFR**.

This is a signed value and can be used to indicate charging or discharging.

9.2.7.16.4. MaximumEnergy Field

This field SHALL indicate the maximum energy that can be transferred to or from the ESA during the constraint period.

This is a signed value and can be used to indicate charging or discharging.

9.2.7.16.5. LoadControl Field

This field SHALL indicate the turn up or turn down nature that the grid wants as the outcome by the ESA during the constraint period.

This is expressed as a signed value between -100 to +100. A value of 0 would indicate no bias to using more or less energy. A negative value indicates a request to use less energy. A positive value indicates a request to use more energy.

Note that the mapping between values and operation is manufacturer specific.

9.2.8. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	ESAType	ESAType-Enum	all	F		R V	M
0x0001	ESACan-Generate	bool	all	F		R V	M
0x0002	ESASTate	ESASTateEnum	desc			R V	M
0x0003	AbsMin-Power	power-mW	all			R V	M