

9.2.8.8. OptOutState Attribute

This attribute SHALL indicate the current Opt-Out state of the ESA. The ESA may have a local user interface to allow the user to control this OptOutState. An EMS may subscribe to the [OptOutState](#) to get notified about changes in operational state.

If the ESA is in the LocalOptOut or OptOut states, so it cannot be controlled by an EMS for local optimization reasons, it SHALL reject any commands which have the [AdjustmentCauseEnum](#) value LocalOptimization. If the ESA is in the GridOptOut or OptOut states, so it cannot be controlled by an EMS for grid optimization reasons, it SHALL reject any commands which have the [AdjustmentCauseEnum](#) value GridOptimization.

If the user changes the Opt-Out state of the ESA which is currently operating with a Forecast that is due to a previous [StartTimeAdjustRequest](#), [ModifyForecastRequest](#) or [RequestConstraintBasedForecast](#) command that would now not be permitted due to the new Opt-out state (i.e. the [Forecast](#) attribute [ForecastUpdateReason](#) field currently contains a reason which is now opted out), the ESA SHALL behave as if it had received a [CancelRequest](#) command.

If the user changes the Opt-Out state of the ESA which currently has the [ESAStateEnum](#) with value [Paused](#) due to a previous [PauseRequest](#) command that would now not be permitted due to the new Opt-out state, and the ESA supports the [PFR](#) or [SFR](#) features (i.e. the [Forecast](#) attribute [ForecastUpdateReason](#) field currently contains a reason which is now opted out), the ESA SHALL behave as if it had received a [ResumeRequest](#) command.

If the user changes the Opt-Out state of the ESA which currently has the [ESAStateEnum](#) with value [PowerAdjustActive](#) due to a previous [PowerAdjustRequest](#) command that would now not be permitted due to the new Opt-out state (i.e. the [Forecast](#) attribute [ForecastUpdateReason](#) field currently contains a reason which is now opted out), the ESA SHALL behave as if it had received a [CancelPowerAdjustRequest](#) command.

If the ESA is in the LocalOptOut, GridOptOut, or NoOptOut states, the device is still permitted to optimize its own energy usage, for example, using tariff information it may obtain.

9.2.9. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	PowerAdjustRequest	client ⇒ server	Y	O	PA
0x01	CancelPowerAdjustRequest	client ⇒ server	Y	O	PA
0x02	StartTimeAdjustRequest	client ⇒ server	Y	O	STA
0x03	PauseRequest	client ⇒ server	Y	O	PAU
0x04	ResumeRequest	client ⇒ server	Y	O	PAU
0x05	ModifyForecastRequest	client ⇒ server	Y	O	FA