

Value	Name	Summary	Conformance
2	PluggedInDemand	The EV is plugged in and is demanding current, but EVSE is not allowing current to flow.	M
3	PluggedInCharging	The EV is plugged in, charging is in progress, and current is flowing	M
4	PluggedInDischarging	The EV is plugged in, discharging is in progress, and current is flowing	V2X
5	SessionEnding	The EVSE is transitioning from any plugged-in state to NotPluggedIn	M
6	Fault	There is a fault, further details in the FaultState attribute	M

9.3.7.3. SupplyStateEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	Disabled	The EV is not currently allowed to charge or discharge	M
1	ChargingEnabled	The EV is currently allowed to charge	M
2	DischargingEnabled	The EV is currently allowed to discharge	[V2X]
3	DisabledError	The EV is not currently allowed to charge or discharge due to an error. The error must be cleared before operation can continue.	M
4	DisabledDiagnostics	The EV is not currently allowed to charge or discharge due to self-diagnostics mode.	M