

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0023	NextChargeStart-Time	epoch-s	all	X		R V	PREF
0x0024	NextChargeTarget-Time	epoch-s	all	X		R V	PREF
0x0025	NextChargeRequiredEnergy	energy-mWh	min 0	X		R V	PREF
0x0026	NextChargeTarget-SoC	percent		X		R V	PREF
0x0027	ApproximateEVEfficiency	uint16	desc	N X	null	RW VM	[PREF]
0x0030	State-OfCharge	percent		X		R V	SOC
0x0031	BatteryCapacity	energy-mWh	min 0	X		R V	SOC
0x0032	VehicleID	string	max 32	X		R V	PNC
0x0040	SessionID	uint32	all	N X		R V	M
0x0041	Session-Duration	elapsed-s	all	N Q X		R V	M
0x0042	SessionEnergy-Charged	energy-mWh	min 0	N Q X		R V	M
0x0043	SessionEnergyDis-charged	energy-mWh	min 0	N Q X		R V	V2X

9.3.8.1. State Attribute

This attribute SHALL indicate the current status of the EVSE. This higher-level status is partly derived from the signaling protocol as communicated between the EVSE and the vehicle through the pilot signal.

The State attribute SHALL change when the EVSE detects change of condition of the EV (plugged in or unplugged, whether the vehicle is asking for demand or not, and if it is charging or discharging).

NOTE

SessionEnding is not really a state but a transition. However, the transition period