

9.3.8.7. MinimumChargeCurrent Attribute

This attribute SHALL indicate the minimum current that can be delivered by the EVSE to the EV.

The attribute can be set using the [EnableCharging](#) command.

9.3.8.8. MaximumChargeCurrent Attribute

This attribute SHALL indicate the maximum current that can be delivered by the EVSE to the EV.

This SHALL represent the actual maximum current offered to the EV at any time. Note that the EV can draw less current than this value. For example, the EV may be limiting its power draw based on the operating conditions of the battery, such as temperature and state of charge.

The attribute can be initially set using the [EnableCharging](#) command or by adjusting the [UserMaximumChargeCurrent](#) attribute.

This attribute value SHALL be the minimum of:

- CircuitCapacity - Electrician's installation setting
- CableAssemblyCurrentLimit (detected by the EVSE when the cable is plugged in)
- MaximumChargeCurrent field in the EnableCharging command
- UserMaximumChargeCurrent attribute

9.3.8.9. MaximumDischargeCurrent Attribute

This attribute SHALL indicate the maximum current that can be received by the EVSE from the EV.

This attribute can be set using the [EnableDischarging](#) command.

This attribute value SHALL be the minimum of:

- CircuitCapacity - Electrician's installation setting
- CableAssemblyCurrentLimit (detected by the EVSE when the cable is plugged in)
- MaximumDischargeCurrent field in the EnableDischarging command

9.3.8.10. UserMaximumChargeCurrent Attribute

This attribute SHALL indicate a maximum current that can set by the consumer (e.g. via an app) as a preference to further reduce the charging rate. This may be desirable if the home owner has a solar PV or battery storage system which may only be able to deliver a limited amount of power. The consumer can manually control how much they allow the EV to take.

This attribute value SHALL be limited by the EVSE to be in the range of: