

- At most once every 10 seconds on changes, or
- When it changes from null to any other value and vice versa, such as at the beginning and end of a charging session.

9.3.8.20.3. SessionEnergyCharged Attribute

This attribute SHALL indicate the energy, in mWh, delivered by the EVSE to the EV for the current or last charging session. A default value of null indicates no sessions have occurred.

The SessionEnergyCharged value can be calculated by knowing the initial value of the energy meter at the start time of the session. Manufacturers SHALL ensure this can be correctly calculated if there has been an power failure or reboot since the start of the session.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once every 10 seconds on changes, or
- When it changes from null to any other value and vice versa, such as at the beginning and end of a charging session.

9.3.8.20.4. SessionEnergyDischarged Attribute

This attribute SHALL indicate the energy, in mWh, received by the EVSE from the EV for the current or last charging session. A default value of null indicates no sessions have occurred.

The SessionEnergyDischarged value can be calculated by knowing the initial value of the energy meter at the start time of the session. Manufacturers SHALL ensure this can be correctly calculated if there has been an power failure or reboot since the start of the session.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once every 10 seconds on changes, or
- When it changes from null to any other value and vice versa, such as at the beginning and end of a charging session.

9.3.9. Commands

ID	Name	Direction	Response	Access	Conformance
0x01	Disable	client ⇒ server	Y	O T	M
0x02	EnableCharging	client ⇒ server	Y	O T	M
0x03	EnableDischarging	client ⇒ server	Y	O T	V2X
0x04	StartDiagnostics	client ⇒ server	Y	O T	O
0x05	SetTargets	client ⇒ server	Y	O T	PREF