

ID	Name	Direction	Response	Access	Conformance
0x06	GetTargets	client ⇒ server	GetTargetsResponse	O T	PREF
0x07	ClearTargets	client ⇒ server	Y	O T	PREF
0x00	GetTargetsResponse	client ⇐ server	N		PREF

9.3.9.1. Disable Command

Allows a client to disable the EVSE from charging and discharging.

9.3.9.1.1. Effect on Receipt

On receipt of this command, the EVSE will stop any power flow between the EV and EVSE.

If the command cannot be handled, a status of FAILURE SHALL be returned.

If the [SupplyState](#) attribute is already Disabled, a response with status of SUCCESS SHALL be returned.

Otherwise, if successful, the [ChargingEnabledUntil](#) and [DischargingEnabledUntil](#) attributes SHALL be set to 0x0, the [SupplyState](#) attribute changed to Disabled, and a response with status of SUCCESS SHALL be returned.

If any energy was being transferred, then a corresponding [EnergyTransferStopped](#) event SHALL be generated.

9.3.9.2. EnableCharging Command

This command allows a client to enable the EVSE to charge an EV, and to provide or update the maximum and minimum charge current.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ChargingEnabledUntil	epoch-s	all	X		M
1	Minimum-ChargeCurrent	amperage-mA	min 0			M
2	Maximum-ChargeCurrent	amperage-mA	min 0			M

9.3.9.2.1. ChargingEnabledUntil Field

This field SHALL indicate the expiry time, in UTC, when charging will be automatically disabled.

A value in the past in this field SHALL disable the EVSE charging whereas a null value SHALL