

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	SessionID	uint32	all			M
1	State	StateEnum	all			M
2	MaximumCurrent	amperage-mA	min 0			M
3	MaximumDischargeCurrent	amperage-mA	min 0			V2X

9.3.10.3.1. SessionID Field

This field SHALL indicate the value of the [SessionID](#) attribute at the time the event was generated.

9.3.10.3.2. State Field

This field SHALL indicate the value of the [State](#) attribute at the time the event was generated.

9.3.10.3.3. MaximumCurrent Field

This field SHALL indicate the value of the maximum charging current at the time the event was generated.

A non-zero value indicates that the EV has been enabled for charging and the value is taken directly from the [MaximumChargeCurrent](#) attribute. A zero value indicates that the EV has not been enabled for charging.

9.3.10.3.4. MaximumDischargeCurrent Field

This field SHALL indicate the value of the maximum discharging current at the time the event was generated.

A non-zero value indicates that the EV has been enabled for discharging and the value is taken directly from the [MaximumDischargeCurrent](#) attribute. A zero value indicates that the EV has not been enabled for discharging.

9.3.10.4. EnergyTransferStopped Event

This event SHALL be generated whenever the EV stops charging or discharging, except when an EV has switched between charging and discharging under the control of the PowerAdjustment feature of the Device Energy Management cluster of the associated Device Energy Management device.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	SessionID	uint32	all			M
1	State	StateEnum	all			M