

9.5.6.3.1. Duration Field

This field SHALL indicate the time period, in seconds, for which the boost state is activated.

9.5.6.3.2. OneShot Field

This field SHALL indicate whether the boost state SHALL be automatically canceled once the hot water has reached either:

- the set point temperature (from the thermostat cluster)
- the [TemporarySetpoint](#) temperature (if specified)
- the [TargetPercentage](#) (if specified).

9.5.6.3.3. EmergencyBoost Field

This field SHALL indicate that the consumer wants the water to be heated quickly. This MAY cause multiple heat sources to be activated (e.g. a heat pump and direct electric immersion heating element).

The choice of which heat sources are activated is manufacturer specific.

9.5.6.3.4. TemporarySetpoint Field

This field SHALL indicate the target temperature to which the water will be heated.

If included, it SHALL be used instead of the thermostat cluster set point temperature whilst the boost state is activated.

The value of this field SHALL be within the constraints of the `MinHeatSetpointLimit` and `MaxHeatSetpointLimit` attributes (inclusive), of the thermostat cluster.

9.5.6.3.5. TargetPercentage Field

This field SHALL indicate the target percentage of hot water in the tank that the `TankPercentage` attribute must reach before the heating is switched off.

9.5.6.3.6. TargetReheat Field

This field SHALL indicate the percentage to which the hot water in the tank SHALL be allowed to fall before again beginning to reheat it.

For example if the [TargetPercentage](#) was 80%, and the [TargetReheat](#) was 40%, then after initial heating to 80% hot water, the tank may have hot water drawn off until only 40% hot water remains. At this point the heater will begin to heat back up to 80% of hot water. If this field and the [OneShot](#) field were both omitted, heating would begin again after any water draw which reduced the [TankPercentage](#) below 80%.

This field SHALL be less than or equal to the [TargetPercentage](#) field.