

For example, if the target temperature was 60°C, the CurrentTemperature was 40°C from a single temperature probe measuring the average water temperature and the temperature of incoming cold water (COLD_WATER_TEMP) was assumed to be 20°C:

```
TankPercentage = int(((current temperature - COLD_WATER_TEMP) / (target temperature - COLD_WATER_TEMP)) * 100)
TankPercentage = min( max(TankPercentage,0), 100)
```

```
TankPercentage = 50%
```

9.5.7.6. BoostState Attribute

This attribute SHALL indicate whether the Boost, as triggered by a Boost command, is currently Active or Inactive.

See Section 9.5.8.1, “Boost Command” and Section 9.5.8.2, “CancelBoost Command” for more details.

9.5.8. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	Boost	client ⇒ server	Y	M	M
0x01	CancelBoost	client ⇒ server	Y	M	M

9.5.8.1. Boost Command

Allows a client to request that the water heater is put into a Boost state.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	BoostInfo	Water-HeaterBoost-InfoStruct	all			M

9.5.8.1.1. Effect on receipt

On receipt of this command, this SHALL allow the water heater to attempt to heat the water, which may override other settings, for example, if the Water Heater Mode is set to Off, or Timed and it is during one of the Off periods.

If the duration field is too short for the water heater to accept, for example a heat pump may take several minutes to ramp up in operation, then the boost command SHALL be rejected with a status of INVALID_IN_STATE.

If successful, the value of the BoostState attribute SHALL transition to Active, and a response with