

9.7.6. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Energy-Balances	list[BalanceStruct]	2 to 10	F		R V	BALA
0x0001	CurrentEnergyBalance	uint8	all	N		RW VO	BALA
0x0002	EnergyPriorities	list[EnergyPriorityEnum]	2	F		R V	BALA
0x0003	LowPowerModeSensitivities	list[BalanceStruct]	2 to 10	F		R V	LPMS
0x0004	CurrentLowPowerModeSensitivity	uint8	all	N		RW VO	LPMS

9.7.6.1. EnergyBalances Attribute

This attribute SHALL indicate a list of [BalanceStructs](#), each representing a step along a linear scale of relative priorities. A [Step](#) field with a value of zero SHALL indicate that the device SHOULD entirely favor the priority specified by the first element in [EnergyPriorities](#); whereas a [Step](#) field with a value of 100 SHALL indicate that the device SHOULD entirely favor the priority specified by the second element in [EnergyPriorities](#). The midpoint value of 50 SHALL indicate an even split between the two priorities.

This SHALL contain at least two [BalanceStructs](#).

Each [BalanceStruct](#) SHALL have a [Step](#) field larger than the [Step](#) field on the previous [BalanceStruct](#) in the list.

The first [BalanceStruct](#) SHALL have a [Step](#) value of zero, and the last [BalanceStruct](#) SHALL have a [Step](#) value of 100.

9.7.6.2. CurrentEnergyBalance Attribute

This attribute SHALL indicate the current preference of the user for balancing different priorities during device use. The value of this attribute is the index, 0-based, into the [EnergyBalances](#) attribute for the currently selected balance.

If an attempt is made to set this attribute to an index outside the maximum index for [EnergyBalances](#), a response with the status code CONSTRAINT_ERROR SHALL be returned.