

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
5	Pow-erThresh-old	Pow-erThresh-oldStruct	all		0		[PWRTHLD].b+
6	Threshold	int64	all	X			M
7	Label	string	max 128	X			O
8	Predicted	bool	all				O

9.12.5.16.1. TariffComponentID Field

This field SHALL indicate an identifier for the tariff component. If the tariff component is not a prediction, this field SHALL be a unique identifier for the combination of values of the [Price](#), [Threshold](#), [FriendlyCredit](#), [AuxiliaryLoad](#), and [PeakPeriod](#) fields with the value of the [DayEntryIDs](#) field on the encompassing [TariffPeriodStruct](#).

Once an identifier has been used for this combination, it SHALL NOT be used to represent any other combination of these values.

9.12.5.16.2. Price Field

This field SHALL indicate the price when the tariff component is active.

When the [Predicted](#) field is set to TRUE, a null value SHALL indicate that the price and/or price level is not yet available.

When the [Predicted](#) field is set to FALSE, a null value SHALL indicate that the server is unable to provide a specific price or price level.

9.12.5.16.3. FriendlyCredit Field

This field SHALL indicate whether the calendar is entering a friendly credit period or not.

NOTE

When a meter enters into a Friendly Credit Period with a usable positive credit balance, the consumer will be allowed to consume energy for the duration of the Friendly Credit Period, regardless of their credit status while in that period. If, however, the consumer had already run out of credit and supply was interrupted before entering into the Friendly Credit Period, they will not be allowed to reconnect without first adding suitable additional credit.

NOTE

At the end of the Friendly Credit Period, the normal delivery rules connected with the accounting functions of the meter will be resumed, and if the meter's credit balance has dropped below the disablement threshold during the Friendly Credit Period, then the meter will disconnect upon resuming normal delivery rules

9.12.5.16.4. AuxiliaryLoad Field

This field SHALL indicate the required state of auxiliary load switches.